

TEL-TRAX

Universal Mounting Bracket Instructions

September 2007

HERE ARE THE INSTALLING INSTRUCTIONS FOR THE NEW UNIVERSAL TOP.

#1 - THERE ARE THREE PARTS TO TOP . A,B,C

A - END RAILS ARE OPEN CHANNEL ON EACH END OF TOP, FRONT AND REAR THAT RUN ACROSS TOP, FROM SIDE TO SIDE.

B - SIDE RAILS MADE WITH 1 1/2" SQUARE TUBING WITH PREDRILLED HOLES, THAT RUN FRONT TO REAR OF TOP.

C - MOUNTING KIT THAT MOUNTS TOP TO ROPS. THIS WILL BE IN A SMALL SEPARATE BOX INSIDE OF TOP.

#2 - INSTALL MOUNTING BRACKET KIT ONTO ROPS OF TRACTOR WITH ANGLE IRON POINTING TOWARD FRONT OF TRACTOR. ANGLE MUST BE JUST ABOVE CROSSBAR OF ROPS, USE THE 4 U-BOLTS AND 8 NYLON INSERT NUTS WITH 8 WASHERS.

#3 - AFTER INSTALLING MOUNTING BRACKET KIT, MEASURE BETWEEN INSIDE OF MOUNTING KIT (FROM SIDE TO SIDE) REMEMBER MEASUREMENTS FOR STEP # 5

#4 - LAY TOP UPSIDE DOWN WITH FRAME FACING UP. LOOSEN EACH END OF SIDE RAILS, SO THEY WILL ADJUST FROM SIDE TO SIDE. (REQUIRES 3/4 WRENCH , NOT INCLUDED)

#5 - TAKE MEASUREMENTS FROM STEP #3 AND ADJUST SIDE RAILS TO MATCH, KEEP IN MIND YOU MUST CENTER RAILS IN TOP SO TOP WILL BE CENTERED OVER TRACTOR. KEEP EQUAL DISTANCE FROM RAIL TO SIDE OF TOP, ON BOTH SIDES.

#6 - TIGHTEN 1/2" HEX BOLTS WITH 3/4" WRENCH, MAKE SURE THAT SPRING NUTS INSIDE OF CHANNEL ARE IN PROPER LOCATION THIS IS A MUST, SO TOP WILL NOT VIBRATE LOOSE. AND SIDE RAILS ARE PROPERLY TIGHTENED. (THIS STEP IS VERY IMPORTANT)

#7 - AFTER CHECKING NUTS INSIDE OF CHANNEL SIT TOP ONTO BRACKETS LETTING ANGLE SUPPORT TOP. INSTALL WITH 4 - 1/2 X 2 3/4 BOLTS AND WASHERS ON EACH SIDE OF BOLT.

#8 - ALL NUTS AND BOLTS SHOULD BE CHECKED REGULARLY FOR TIGHTNESS.